

The JA-116E, JA-116E-AN, JA-116E-GR BUS touchscreen keypad with RFID reader

The keypad is a component of the **JABLOTRON** system and is designed to be operated by touch. The keypad must be installed by a trained technician with a valid **JABLOTRON** certificate issued by an authorised distributor. **This product is compatible with JA-102K, JA-103K, JA-107K and JA-108K control panels.**

This manual must be used together with the installation and user manual of the JABLOTRON control panel system.

The keypad components are shown in the following figures:




Figure 1 – front part: 1 – touchscreen; 2 – button/LED system indicator; 3 – RFID reader – reading area




Figure 2 – internal part: 4 – connection points of the BUS terminal; 5 – serial number; 6 – tamper contacts; 7 – USB-C connector; 8 – locking mechanism; 9 – rear part tab





Figure 3 – back part: 10 – BUS terminal; 11 – screw holes

Installation

1. Remove the back part (Fig. 3) of the keypad. If it cannot be removed easily, open the locking mechanism, see chapter "Keypad disassembly".
2. In the back part, break out the blank of appropriate slot, pull the BUS cable through, and then screw the back part of the keypad to the designated place, preferably on a solid base (wall). Select the installation height of the keypad with respect to the height of the users. The ideal height for good readability and control is at eye level. It is not recommended to mount at a height consistent with electrical switches (100-110 cm).
3. Connect the individual wires of the BUS cable to the BUS terminal (10) as follows:
 - a) Using a flat screwdriver to press upper side of the terminal.
 - b) Put a stripped wire into the appropriate terminal.
 - c) Release the terminal.
 - d) Test if the wire is correctly fixed with a gentle pull.



+U – red; positive power supply pole
A – yellow; data wire A
B – green; data wire B
GND – black; negative power supply pole

Notes:

- Connect only straight, stripped wires to the BUS terminals (their ends only).
- Use a narrow flat screwdriver to turn the locking mechanism and release the tab.



Always switch the power off before connecting the keypad to the BUS.

4. First, attach the bottom edge of the keypad to the back part (align the bottom sides) and slide in downwards until you hear the click of the tab (9). This will secure the keypad against falling out of the back part (Fig 3). Then turn the locking mechanism (8) clockwise 90° to the position where the groove points to the symbol This locks the keypad in place and engages the tamper contact.
5. Power the system on.
6. Enrol the keypad to the system according to the type of control panel, use the recommended software or application, see the installation manual of the control panel.

Notes:

- Enrolment is possible by entering the serial number (5) in the F-Link software or appropriate application. All numbers stated under the bar code must be entered (1400-00-0000-0001).
- Another enrolment option is using F-Link software, within the Devices tab -> Scan/Add new BUS devices; or by pressing the button (2).

Installation accessories

JA-106PL – JA-116E and JA-156E surface mounting pad

The JA-106PL surface mounting pad is available for JA-116E keypads, allowing installation on surfaces where it is not possible to run the cable under the plaster. The pad allows surface wiring from all four sides, typically using an installation rail. For quick installation, break-out holes are provided on all sides for threading the wiring. During installation, it is necessary to maintain the UAM function and protection against removal of the keypad from the mounting surface.

Also available in JA-106PL-AN variant.

Note:

- The JA-106PL pad is not comply with INCERT requirements.

The JA-116E, JA-116E-AN, JA-116E-GR

BUS touchscreen keypad with RFID reader

Keypad disassembly

On the underside of the keypad, turn the locking mechanism (8) counterclockwise 90° until the groove points to the symbol . Insert the flat screwdriver into the tab hole (9) (push the screwdriver towards the wall) while sliding the keypad upwards. The keypad can then be easily removed from the back part (Fig. 3).

Authorisation – can be done by entering a valid access code on the virtual keypad or by applying the access card / chip. Authorization will terminate itself after 15 seconds from the last detected touch on the screen, or immediately by pressing the button (2), or it can be terminated by the logout icon in the upper left corner. The individual keypad screens and menus and the system control options are based on the user access rights configured in the control panel.

Setting the properties

The settings are configured by the F-Link software – **Devices** tab. Use the **Internal settings** option on the device position. A dialogue window will appear in which all the keypad functions can be configured. See also the F-Link help bubble for details on the settings.

*Factory parameter settings are marked with *.*

Assigned sections = Selection of system sections (all are selected from factory), which are acoustically and optically indicated by the keypad and are always displayed in the keypad menu on the section tab (regardless of the authorized user's permissions).

Assigned PG's = Selection of PG outputs from the system (no PG outputs are selected from the factory), which are acoustically signalled by the keypad and are always displayed on the PG tab (regardless of the authorised user's permissions).

Control without authorization - control is ***disabled** by default.

Sections with Control without authorization = Selection of sections (none are factory selected) that can control (arm) the system from the home screen without the need for authorization, they are acoustically, visually indicated by the keypad and are always all displayed in the keypad menu on the section tab (regardless of the authorized user's permissions).

PG with control without authorization = Selection of PG outputs (none are factory selected) that can be controlled. They are acoustically indicated by the keypad and are always displayed on the PG tab (regardless of the authorized user's permission).

Optical indication

Automatic backlight regulation - Day

Automatically adjusts the light intensity of the display and the LED system indicator (2) under the display according to the ambient light in day mode.

Backlight intensity Day – Allows manual adjustment of LED system indicator (2) light intensity and display backlight in four steps when day mode is active: minimal, low, medium, ***high**.

Automatic backlight regulation – Night

Automatically adjusts the light intensity of the display and the LED system indicator (2) under the display according to the ambient light in night mode.

Backlight intensity Night – Allows manual adjustment of LED system indicator (2) light intensity and display backlight in four steps when night mode is active: ***minimal**, low, medium, high.

System status optical indication by button / LED system indicator

The button / LED system indicator (2) indicates system status according to the following priorities:

1. USB-C cable connected/preparing for FW update – continuously lit green while the cable is connected.
2. BOOT mode / FW update - very short yellow flash with 1s pause while BOOT mode is active (FW update).
3. Keypad disabled (bypass) – LED system indicator off (keypad disabled in F-Link SW - red dot); lasts for the duration of keypad disablement.
4. Not enrolled to the system - yellow flashing at 2 Hz until it is enrolled to the system.
5. Full arming/unauthorised user/entry delay - green flashing at 2 Hz for the duration of the full arming if there is no authorised user.
6. Full arming/unauthorised user - no indication, for the duration of the full arming, if there is no authorised user.

7. Keypad Internal settings open – permanently lit yellow, for the duration of settings being open.
8. Loss of communication – permanently lit yellow for the duration of the loss.
9. Indicates activation and deactivation of the keypad's own tamper contact - short red flash; 1x flash during activation and deactivation of tamper contact in Service or Maintenance mode.
10. Pending information* - quick yellow flash with a pause, only indicates if there is no authorized user and for the duration of the pending information.
11. Pending information in power saving mode* - fast yellow flashing with long pause - only during power failure.
12. Service mode – fast yellow flashing; while Service mode is open.
13. Maintenance mode – fast green flashing; while Maintenance mode is open.
14. Alarm ongoing / pre-alarm - rapid red flashing; for the duration of the alarm.
15. Alarm memory - two quick red flashes and a pause; until the alarm memory indication is cancelled.
16. Unsuccessful setting - rapid yellow flashing; for the duration of the unsuccessful setting.
17. Unsuccessful setting in power saving mode - slow yellow flashing; for the duration of unsuccessful setting.
18. Entry delay - slow green flashing; for the duration of the entry delay time.
19. System fault – permanently lit yellow; out of power saving mode for the duration of the fault.
20. Authorized user - permanently lit green; for the duration of the valid authorization.
21. Everything OK without authorization request - does not light up until status change.

Notes:

- *The LED system indicator (2) provides indications even when the screen is off.*
- ** Pending information serves as a warning to the authorized user of some "pending" indication or information that cannot be displayed to an unauthorized user in a given system profile. Pending information is indicated if the system has an EN50131-1 or Incert profile on when the Alarm, Alarm Memory, Fault, Service or Maintenance mode occurs.*

Acoustic indication

Description of keypad's acoustic indication settings.

Day volume = Adjusts the volume of the acoustic indication when the day mode is active. Adjustable in four steps: off, low, medium, ***high**.

Night volume = Adjusts the volume of the acoustic indication when the night mode is active. Adjustable in four steps: off, ***low**, medium, high.

Alarm and Unsuccessful setting indication = Adjusts the volume of the acoustic indication of alarm and unsuccessful setting regardless of other acoustic indication (exit / entry delay, ...).

- ***Always full** = The keypad will always indicate an alarm and unsuccessful setting acoustically at full volume, regardless of the keypad volume setting and day / night mode.
- **According to the intensity setting** = The keypad will acoustically indicate an alarm and unsuccessful setting at the same volume as other acoustic indications.
- **No** = The keypad will not indicate alarm and unsuccessful setting acoustically.

Exit delay indication – Configures under which conditions the exit delay should be acoustically indicated.

- **No** = The keypad will not acoustically indicate exit delay.
- **When fully armed** = The keypad will acoustically indicate the exit delay only when the section is fully armed.
- ***Always** = The keypad will acoustically indicate the exit delay when the section is fully or partially armed.

Entry delay indication – ***Enable** / disable acoustic indication during entry delay.

Section status change - ***Enable** / disable acoustic indication when section status changes.

PG status change - Enable / ***disable** acoustic indication when the PG status changes.

Pressing indication - ***Enable** / disable acoustic indication when pressing the touchscreen.

The JA-116E, JA-116E-AN, JA-116E-GR BUS touchscreen keypad with RFID reader



JABLOTRON



Acoustic indication of individual system states

Acoustic indication of system states according to their priorities:

1. Confirmation of action - short higher tone 1.2 kHz.
2. Action denied - short lower tone 400 Hz.
3. RFID card/tag detection - 1x short beep 2 kHz.
4. Valid authorization - 1x short higher tone beep 3.2 kHz.
5. Invalid authorization - 1x short lower tone 400 Hz.
6. Card code / card code confirmation request - 2.2 kHz.
7. Alarm - long drawn tone 3 kHz for the during alarm.
8. Entry delay - uninterrupted 1.25 kHz tone for the during entry delay.
9. Unsuccessful setting - repeated 1.25 kHz short tone until the unsuccessful setting indication is cancelled.
10. Exit delay - beeps at 1.25 kHz during the exit delay.
11. Change section status - 1x beep with 2 kHz tone.
12. PG output status change - 1x short beep with 2 kHz tone.

Thermometers

Temperature 1 and 2 – The measured temperature from the selected devices will be displayed on the Temperature tab and on the lock screen.

Temperature 3 to 8 – The measured temperature from the selected devices will be displayed on the Temperature tab.

Note:

- A maximum of 8 temperature meters assigned to the system can be set to be displayed.

Special options

Lock screen – Sets the period of time that the display will show the lock screen (Includes time, date, temperature) before the display is completely turned off.

Optional intervals: *Off, 1 min.

Display Temperature - displays the temperature on the keypad lock screen.

Display clock - displays the hour and date on the keypad lock screen.

Background wallpaper - select the image displayed on the keypad lock screen in the following modes:

- Disabled - the lock screen background is black.
- 24 h mode - the background wallpaper changes every day at midnight
- Display permanently - permanent display of one of 7 background wallpapers, if you select this option the following parameter will appear within the wallpaper selection.

Static wallpaper mode - if static display is selected a choice of 7 background wallpapers is available.

Card reader – The setting allows you to permanently disable the card reader.

Service contact – Used to fill in the contact details of the service company.

Installation company – Allows to enter the name of the installation company, which will be visible to all users in the keypad menu.

Phone number – Allows to enter the name of the installation company, which will be visible to all users in the keypad menu.



A keypad configuration which complies with certification requirements must be selected from the list of System profiles in the system Parameters tab of the F-link SW.

Firmware update

It is done via the F-Link software using a USB-C cable or via BUS and must be performed by a user with Service level authorization.

1. Start the F-Link software and open the existing database of the system.
2. Enter the service mode and (if updating via USB-C) remove the keypad from the back part (Fig. 3).
3. If updating via USB-C then connect the keypad to a PC.
4. Select **Control Panel** → **Firmware Update** from the toolbar.
5. In the device menu table, select the required device; if Automatic Update is disabled, select the FW package file (included in the F-Link software or can be published for download separately, file type *.fwp).

6. Press **OK** to update the selected device.
7. After the update is complete, check the keypad settings with **F-Link, Devices / Internal settings**. Depending on the changes made during the update, the previous keypad settings may be retained or reset to factory defaults.

Note:

The device firmware can be updated over the system BUS without a USB connection, but the update time exceeds 10 min.

Technical specifications

Type of control device	type B
Power	from control panel bus 12 V DC (8–15 V)
Current power consumption for backup chose	40 mA
Nominal current consumption (display OFF)	118 mA
Maximal current consumption (for cable selection)	240 mA
RFID frequency	125 kHz
For GRADE 3 profile, the RFID reader is turned off and authorization is only possible by entering a code!	
Maximum RFID magnetic field strength	-5.4 dBuA/m (measured at 10 m)
Dimensions	94 x 183 x 31 mm
Weight	248 g
Classification	Security grade 3 / Environmental class II (According to EN 50131-1)
Environment	indoor general
Operating temperature range	-10 °C to +40 °C
Average operational humidity	75 % RH, non- condensation
Certification body	Trezor Test s.r.o. (nr. 3025), Kiwa Nederland b. v.
In compliance with	EN 62311, ETSI EN 300 330, EN 50130-4, EN 55032, EN 62368-1, EN IEC 63000, EN 50131-3, T 031
Can be operated according to	ERC REC 70-03
Recommended screw	4x  ø 3.5 x 40 mm (half-round head)



JABLOTRON a.s. hereby declares that the JA-116E, JA-116E-AN and JA-116E-GR is in a compliance with the relevant Union harmonisation legislation: Directives No: 2014/53/EU, 2014/35/EU, 2014/30/EU, 2011/65/EU. The original of the conformity assessment can be found at www.jablotron.com – Section Downloads

Note: Disposing of this product correctly will help save valuable resources and prevent any potential negative effects on human health and the environment, which could otherwise arise from inappropriate waste handling. Please return the product to the dealer or contact your local authority for further details of your nearest designated collection point.



JABLOTRON a.s.
Pod Skalkou 4567/33 | 46601 | Jablonec n. Nisou
Czech Republic | www.jablotron.com

